

Limit Lines on the SSA3000X Spectrum Analyzer

October 23, 2017

The SIGLENT SSA3000X series of spectrum analyzers feature two limit lines that can be used to visually identify whether a signal or spectrograph meets or exceeds given parameters.

Limit lines can be used for:

- EMI Pre-compliance measurements using FCC/CISPR limit lines
- Transmitter testing: Is the signal in the proper band?
- AM NRSC measurements

SSA3000X Limit Line Features:

- Two limit lines can be activated at any time

- Each limit line can be either an upper or lower limit. Upper limits define maximum values and lower limits define minimums.

Each limit line has two modes: Line or point. Lines are single lines that exist at a user-defined amplitude.
Point defined limits are build using line segments and can be used to build complex limits, like NRSC masks.

In this FAQ, we are going to build an upper limit line based on the conducted emissions for a class B unintentional radiator per the FCC Subpart 15 regulations using the point method.

The specifications for FCC Subpart 15, Class B unintentional radiators is given as:

Frequency of emis- sion (MHz)	Conducted limit (dBµV)		
	Quasi-peak	Average	
0.15–0.5 0.5–5 5–30	66 to 56* 56 60	56 to 46* 46 50	

*Decreases with the logarithm of the frequency.

1. Configure the instrument to cover the frequency span of interest (150 kHz – 30 MHz, in this case) by pressing the button marked Frequency on the front panel and entering the start and stop frequencies.

2. The limits are given in amplitude units of dBuV. To set the SSA units, press Amplitude and set Units to dBuV.

3. Press the Limit button to open the Limit menu. Set Limit1 to ON to activate the Limit menus.

- 4. Press Limit1 Edit > Set Type to Upper
- 5. Set Mode to Point
- 6. Press the grey colored soft key next to the entry labeled X Axis and enter the frequency for the first data



point, 150 kHz

SIGLENT	2017-03-10 03:23:37	Limit 1 Efet
LOG	Ref 106.99 dBuV Att 20.00 dB	Type Type
10 dB	97	Upper Lower Span Marker Syste
	87 X Avás	Mode Marker Marker System
Free	67 150.000 kHz	Line Point Amplitude
LgPwr		Add Point Peak Fn Mode
Conc	37 "White the structure of the structure os structure of the structure os structure of the structure os structure os structure of the structure os structure os structure os structure os structure os structure o	Auto Tune Measure
		X Axis Meas Setup
		Edit
	Start 150.000 kHz Step 30.00000 MHz RBW 300.000 kHz VBW 300.000 kHz SWT 48.000 ms	Amplitude 56.00 dBuV
A CBW	Limit Table	TA/a Zabe J car Back
	Non Limit X Avia Amet Non Limit X Avia Amet	Del Point 4 ghi 5 pt 6 mno
	1 150.000 kHz 56.00 dBuV 1 1.60000000 GHz 6.99 dBuV	Esc
		Del All 7 pqrs 8 tuv 9 wxyz
		Enter
		Local
Construction of the local division of the lo		TG SOURCE RF INPUT

7. Press the grey colored soft key next to the entry labeled Amplitude and enter the Average start amplitude, 56 dBuV. If using a Quasi-peak detector, use the Quasi-peak values of the chart.



8. Press Add Point and enter X Axis and Amplitude values for the second point, 500 kHz and 46 dBuV. Now,



we have two points (1 and 2) form the first line segment of the limit line.

9. Press Add Point to enter the third point, which corresponds to the start of the second line segment. Note that the end point for one line segment has the same value as the starting point of the next line segment.

10. Continue to add points until you have finished the entire limit line. Confirm that the limit line and corresponding table match your limits



11. You can go to a full-screen limit line view by pressing the "back arrow" shown below:

SIGLENT[°]

SIGLENT SSA 3032X Executed Addresses	96472-3.20442	Control Setting Prequency Trace Detect Limit	TG Preset Demod Couple
10.0 db 97 97 97 97 9 9 9 10 9 10 9 10 9 10 9 10 10 10 10 10 10 10 10 10 10		Span Marker System Amplitude Auto Turn Meas Meas Meas	File Save
A CAW P-9X A CAW P-9X	3 to be a constraint of the constraint of t	Edit 1 A/2 2 x 3 647 4 40 5 /4 6 mm 5 x 8 tor 9 mm 7 mm 8 tor 9 mm Enter	
		TG SOURCE RF INPUT	



12. Save the limit line to internal memory or an external USB memory stick using the Save button

SIGLENT[®]

North American Headquarters

SIGLENT Technologies America, Inc 6557 Cochran Rd Solon, Ohio 44139 Tel: 440-398-5800 Toll Free:877-515-5551 Fax: 440-399-1211 info@siglent.com www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES EUROPE GmbH Staetzlinger Str. 70 86165 Augsburg, Germany Tel: +49(0)-821-666 0 111 0 Fax: +49(0)-821-666 0 111 22 info-eu@siglent.com www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD. Blog No.4 & No.5, Antongda Industrial Zone, 3rd Liuxian Road, Bao'an District, Shenzhen, 518101, China. Tel:+ 86 755 3661 5186 Fax:+ 86 755 3359 1582 sales@siglent.com www.siglent.com/ens