

## Firmware Update Instructions

**Notes:** 1. During the updating, do not cut off the power or pull out the U-disk

1. Please firstly copy the update file (.ADS) to U-disk.
2. Insert the U-disk to the USB port.
3. Press **System** button and then press **Upgrade**, Use the knob or touch screen to select the right update firmware. Then press **OK**, Press the **YES** and will see the upgrading information ('hourglass and please do not power off or unplug your machine. Installing update'). This upgrade program will take about 2~3 minutes.




Figure 1 System menu




Figure 2 Update

4. When the device upgrading finished, it will restart by itself. We can check the version information in system info(System--About).




Figure 3 System info