

## Firmware Update Instructions

**Notes:** 1. During the updating, do not cut off the power or pull out the U-disk

1. Please firstly copy the update file (.ADS) to U-disk.
2. Insert the U-disk to the USB port.
3. Press **Menu** button and then press **System**, and press **Service**, we can enter **Service** interface.






Figure 1 System menu

4. Press **Upgrade** and then enter the file system. Use the knob or touch screen to select the right update firmware. Then press **OK**, we will see an information window. Press the **Yes** and will see the upgrading information ('hourglass and Please do not power off or unplug your machine. Installing update ...') This upgrade program will take about 2~3 minutes.






Figure 2 Update interface

5. When the device upgrading finished, it will restart by itself. We can check the version information in system info(Menu--System--Utilities--About).




Figure 3 System info