

## Revise History

Date	Version	Revision
2022/01/11	2.1.1.9	1. Add the OCP function (Long push “Fine” to enter or exit OCP function). .
2023/03/10	2.1.1.9R1	2. Modify the BUG that is not saved when setting IP manually.
2025/06/10	2.1. <b>2</b> .12R2	3. Add the OVP function 4. The MCU has been changed to <b>GD32F427</b> . Firmware versions 2.1. <b>1</b> .XXX cannot be upgraded.

## Version compatibility

Source Version	Object Version	Compatibility
2.1.1.9R1	2.1.1.9	YES
2.1. <b>2</b> .12R2		<b>NO</b>

## Update instructions

- 1、 To upgrade you firmware, you should download EasyPower(please download it on <https://siglentna.com/>) to your computer. And then you can upgrade your firmware via USBTMC.