

SDS2000X Firmware Update Instructions

Note: during the updating, do not turn off the power or pull out the U-disk.

1. First, unzip the firmware file (.ads) in the update package to a U-disk (thumb drive).
2. Insert the U-disk into the USB port on the front of the oscilloscope.
3. Press **Utility** and then **Next Page** to get to the third page of the UTILITY function menu.




Figure 1 UTILITY function menu

4. Press **Update** and then choose **Firmware** to enter the file system.




Figure 2 File system

5. Use the universal knob to select the new update firmware which will be the .ads file, and then press the **Press To Update** softkey. Next press the **Single** button to start the upgrade program. The program will take approximately 5-6 minutes to load.
6. After seeing the prompt, "Update Success! Please Restart the SPO", please restart the oscilloscope.



Figure 3 Update successfully

Note: during the updating, do not turn off the power or pull out the U-disk.