

## SHS additional isolation details

**December 28, 2021** 

The SHS series can operate without the battery when they are plugged into a working wall outlet using the supplied charger.

For the SHS1000 models, Channel-to-channel isolation, as well as channel-to-ground isolation, is maintained.

The ground of the battery charger and mainboard (data processing part) are not isolated.

The SHS800 series does not have the same level of isolation. Its channel -to-channel, channel-to-ground, battery charging, and the mainboard (data processing part) use the same reference ground.



## **North American Headquarters**

SIGLENT Technologies America, Inc 6557 Cochran Rd Solon, Ohio 44139

Tel: 440-398-5800 Toll Free:877-515-5551 Fax: 440-399-1211 info@siglent.com

www.siglentamerica.com/

## **European Sales Offices**

SIGLENT TECHNOLOGIES EUROPE GmbH Staetzlinger Str. 70 86165 Augsburg, Germany Tel: +49(0)-821-666 0 111 0

Fax: +49(0)-821-666 0 111 22

info-eu@siglent.com www.siglenteu.com

## **Asian Headquarters**

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel:+ 86 755 3661 5186
Fax:+ 86 755 3359 1582

sales@siglent.com
www.siglent.com/ens