

SDS1000DL+/CML+_ Firmware Update Instructions

Notes:

Before updating the ADS file, the ADS file need to be renamed and ensured that its name is less than 9 letters.

Update Procedure:

1. Unzip the .RAR file and copy the .ADS file to a flash drive.
2. Insert the flash drive into the USB interface on the front panel of the oscilloscope.
3. Press the “Utility” button on the front panel to enter the UTILITY function menu.
4. Press the “Next Page” softkey to go to the third page of the UTILITY function menu.
5. Press the “Update Firmware” softkey to enter the UPDATE function menu.
6. Follow the instructions at the bottom of the display and “Press ‘Single’ to update and press “Run/Stop’ to cancel
7. Press the “Single” button and a window will open to show you the files on the flash drive.
8. Turn the “Universal Knob” to select the ADS file to perform the update.
9. When the ADS file to perform the update is highlighted press the “Load” softkey.
10. A window will open showing the system updating and progress bar. When it finished, The SPO will restart itself.
11. Press the “Utility” button on the front panel to enter the UTILITY function menu.
12. Press the “Next Page” softkey to go to the second page of the UTILITY function menu.
13. Press the “Do Self Cal” softkey to perform the self-calibration.
14. Follow instructions to “Press ‘Single’ key to begin.”
15. Window will open showing self-calibration in process. When process finishes “Press ‘Single’ key to exit.”
16. To verify the software version press the “Utility” button and go to the first page of the UTILITY function menu.
17. Press the “System status” softkey and confirm the version number under “Software version” matches your update version.