

## Revision History

| Date      | Version  | Revision  |
|-----------|----------|---|
| 2017/7/06 | 5.1.3.13 | <ol style="list-style-type: none"><li>1. Cursor values not correct if probe attenuation was not set to 1X</li><li>2. Removed channel input impedance of 50Ω</li><li>3. Added extern load setting to FFT menu. If using an external load, amplitudes can be shown in dBm</li><li>4. Repaired intermittent lock up after enabling decoding function</li><li>5. Optimized translation for German and English menus and pop messages</li><li>6. Removed Option label from UI</li><li>7. Corrected cursor measurements for active Zoom with FFT</li><li>8. Added telnet(port 5024) and open socket(port 5025) for LAN communication</li><li>9. Fixed blank zoom bug. With both channels at 2 ms/div, 7 Mpts, and a zoom of 500 ns/div, the zoom window would blank.</li><li>10. Fixed decode threshold levels for 10X probe attenuation selection.</li><li>11. Fixed average mode. After pressing [Run/Stop] to halt acquisition, the display changed to the last waveform, rather than maintaining the averaged waveform</li><li>12. Remain the final message for firmware update until rebooted</li><li>13. Fixed the issue with Chinese language setting after self-calibration.</li><li>14. Fixed the CAN source bug. If the source selected was CANH or CANL, decode would not work correctly.</li><li>15. Decreased waveform jitter with active measurements or math with horizontal delay out of the screen.</li><li>16. Added progress information while saving CSV files.</li><li>17. Fixed the Cycle RMS measurement does not update when the input signal changes</li><li>18. Keep "Print" picture type in accordance with the type selected from "Save/Recall"</li><li>19. Fixed user file renaming of a previously saved file.</li><li>20. Enabled decoding for time bases above 20ms/div.</li><li>21. Disable menu if cursors, measurement and math is disabled</li><li>22. Finished updates to support EasyScopeX and Labview driver.</li></ol> |

| Date      | Version | Revision                               |
|-----------|---------|--|
|           |         | 23. Optimized channel self-calibration |
| 2017/3/22 | 5.1.3.8 | Initial formal release                 |

## Compatibility between Versions

| Source<br>Version | Object<br>Version | Compatibility |
|-------------------|-------------------|---------------|
|                   |                   |               |