

How to view multiple traces without all of them using the QuasiPeak Detector setting

March 19, 2020

The SIGLENT SSA3000X, SSA3000X Plus, and SVA1000X products all have an EMI option that adds a Quasi-Peak detector selection.

The Quasi Peak detector is an integrating detector type that will automatically apply to all active traces on the analyzer.

To prevent existing traces from being overwritten with the Quasi Peak detector data, please follow these steps:

First, activate all traces that are NOT Quasi Peak (pos peak/neg peak/sample/normal average detect type).

When the sweep has finished, then set these trace types to view. This will freeze them on screen.

Next, set the other trace to Quasi-peak and collect the data.



North American Headquarters

SIGLENT Technologies America, Inc
6557 Cochran Rd Solon, Ohio 44139
Tel: 440-398-5800
Toll Free: 877-515-5551
Fax: 440-399-1211
info@siglent.com
www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES EUROPE GmbH
Staetzlinger Str. 70
86165 Augsburg, Germany
Tel: +49(0)-821-666 0 111 0
Fax: +49(0)-821-666 0 111 22
info-eu@siglent.com
www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel: + 86 755 3661 5186
Fax: + 86 755 3359 1582
sales@siglent.com
www.siglent.com/ens