

SPD Local Front Panel Lock Out SCPI commands

November 21, 2019

The current version of the SPD programming commands (located in the Quick Start Guide) do not include any front panel lock commands. These are typically used to control the functionality of the front panel keys. Locking the front panel prevents accidental changes to instrument operation during remote control. The SPD1000X and SPD3303X/X-E have three commands (SPD3303C only uses command 1 and 2):

1. **"*LOCK"** - Locks out the function of the front panel buttons.
2. **"*UNLOCK"** - Unlocks the function of the front panel buttons.
3. **"*LOCK?"** - This is a query that asks the instrument the current state of the lock feature.



North American Headquarters

SIGLENT Technologies NA
6557 Cochran Rd Solon, Ohio 44139
Tel: 440-398-5800
Toll Free: 877-515-5551
Fax: 440-399-1211
info@siglent.com
www.siglentna.com

European Sales Offices

SIGLENT TECHNOLOGIES GERMANY GmbH
Liebigstrasse 2-20, Gebaeude 14,
22113 Hamburg Germany
Tel: +49(0)40-819-95946
Fax: +49(0)40-819-95947
info-eu@siglent.com
www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel: + 86 755 3688 7876
Fax: + 86 755 3359 1582
sales@siglent.com
www.int.siglent.com