

Bode using LAN


October 13, 2022

Many SIGLENT SDS oscilloscopes, including the SDS6000A series, can perform automated Bode plotting to provide frequency response for [power supply stability](#), [filters](#), and more. This integrated approach simplifies testing and delivers results much more quickly than building your own system, integrating separate instruments with software and an external controlling computer.

In the examples above, we used USB to connect the controlling oscilloscope to the external function generator.

In this operating tip, we show how to connect a SIGLENT SDS6000A oscilloscope and an SDG1000X series arbitrary waveform generator using a direct LAN connection for use with the SIGLENT Bode application.

1. Connect the LAN port of the scope to the LAN port of the SIGLENT SDG generator:




2. Set the full IP address, Subnet mask, and Gateway for the SDG by entering the Interface menu (SDG1000X Press Utility > Arrow over to page 2/2 > Interface > LAN state ON and press LAN Setup):

IP Address:	192 , 168 , 1 , 2
Subnet Mask:	255 , 255 , 0 , 0
Gateway:	192 , 168 , 1 , 1

IP Address	Subnet Mask	Default Gateway	DHCP Off	Accept	Cancel
------------	-------------	-----------------	----------	--------	--------


3. Set the full IP address, Subnet mask, and Gateway for the SDS scope (SDS6000A Press Utility > I/O > LAN Config):




NOTE: The Gateway and Subnet Mask values for both instruments need to be identical. The first three triplets of the IP address must also be the same. If they are not, the connection will fail.

4. Set the function generator IP address in the Bode II application by opening the Bode menu. On the SDS6000A, press Analysis > Bode.


That will open the Bode menu as shown:




Select Configure> Set the interface as LAN and set the IP address ***of the generator*** into the text box:



Here is the generator LAN configuration page, for reference:



5. Test the connection by pressing Test:



Once you have the connection working, you can configure your Bode plot and start taking data.

The most common problems center around cabling. Are they connected to the proper instruments? Proper ports? Are the cables ok?

Other issues tend to center around the LAN settings. Check them again before contacting support for additional help.



North American Headquarters

SIGLENT Technologies America, Inc
6557 Cochran Rd Solon, Ohio 44139
Tel: 440-398-5800
Toll Free: 877-515-5551
Fax: 440-399-1211
info@siglent.com
www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES EUROPE GmbH
Staetzlinger Str. 70
86165 Augsburg, Germany
Tel: +49(0)-821-666 0 111 0
Fax: +49(0)-821-666 0 111 22
info-eu@siglent.com
www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel: + 86 755 3661 5186
Fax: + 86 755 3359 1582
sales@siglent.com
www.siglent.com/ens