

## Programmatically selecting a built-in arbitrary waveform with an SDG

February 15, 2019

The SDG series of arbitrary waveform generators have a number of built-in arbitrary waveforms including health-related waveforms like cardiac and math waveforms like sinc.

To read the available waveforms, you can send the following string:

STL?

This will return a list similar to the following (the exact return data depends on the instrument model and firmware revision):

```
STL\sM10,\sExpFal,\sM100,\sECG14,\sM101,\sE
```

The list is comprised of a waveform index and a name.

For example, if you wish to recall the ExpFal waveform send:

```
C2:ARWV INDEX 10
```

Where C2 = Channel 2

NOTE: The “M” in the index return string is dropped when sending the ARWV command string.



### **North American Headquarters**

SIGLENT Technologies America, Inc  
6557 Cochran Rd Solon, Ohio 44139  
Tel: 440-398-5800  
Toll Free: 877-515-5551  
Fax: 440-399-1211  
[info@siglent.com](mailto:info@siglent.com)  
[www.siglentamerica.com/](http://www.siglentamerica.com/)

### **European Sales Offices**

SIGLENT TECHNOLOGIES EUROPE GmbH  
Staetzlinger Str. 70  
86165 Augsburg, Germany  
Tel: +49(0)-821-666 0 111 0  
Fax: +49(0)-821-666 0 111 22  
[info-eu@siglent.com](mailto:info-eu@siglent.com)  
[www.siglenteu.com](http://www.siglenteu.com)

### **Asian Headquarters**

SIGLENT TECHNOLOGIES CO., LTD.  
Blog No.4 & No.5, Antongda Industrial Zone,  
3rd Liuxian Road, Bao'an District,  
Shenzhen, 518101, China.  
Tel: + 86 755 3661 5186  
Fax: + 86 755 3359 1582  
[sales@siglent.com](mailto:sales@siglent.com)  
[www.siglent.com/ens](http://www.siglent.com/ens)